

(8) Square nuts, (8) 1/4" x 3/4" Hex bolts, CONTENTS: (2) Mounting plates,

(8) Lock washers and (8) Flat washers

**CADARAC**™

Freely reposition along accessory track

 Universal traction board mounting plate

Reorder #4007184

Quick and easy installation

## ADATRAC™ MOUNTING PLATE

# MOUNTING PLATE INSTRUCTIONS

### TOOLS: Protective eyewear, ratchet with 7/16" socket

9/16" socket and 9/16" wrench (optional)

## SAFETY INFORMATION

- Always distribute weight evenly
- Verify ADARAC<sup>TM</sup> and ADATRAC<sup>TM</sup> are mounted
- Always use caution when loading or unloading cargo securely before loading cargo or operating truck
- Adhere to safety warnings and cautions outlined in
- ADARACTM and ADATRACTM Accessories Installation
- Instructions (available at adarac.com)
- Only use ADATRAC<sup>™</sup> Mounting Plates with bolt on

### accessories

### INSTALLING MOUNTING PLATE

A. Insert (2) square nuts in top and bottom nut channel of ADATRAC $^{TM}$ .

**TIP:** If installing optional accessories, insert mounting hardware in accessory track nut channels before attaching to uprights.

- B. Place lock washers and flat washers on bolts.
- C. With mounting plate in desired location, align mounting holes with nuts in top and bottom nut channels.
- D. Insert bolts with lock washers and flat washers, then finger tighten to square nuts.
- E. Fully tighten and secure all bolts on mounting plate.
- F. Repeat Steps A-E for remaining mounting plates.

IMPORTANT: Verify mounting plates are mounted securely before loading cargo or operating truck.

