



- Always distribute weight evenly
- Verify ADARAC™ and ADAGRID™ are mounted securely before loading cargo or operating truck
- Always use caution when loading or unloading cargo
- Adhere to safety warnings and cautions outlined in ADARAC™ and ADAGRID™ Accessories Installation Instructions (available at [adarac.com](http://adarac.com))
- Only use ADAGRID™ Mounting Plates with bolt on accessories

#### SAFETY INFORMATION

**TOOLS:** Protective eyewear and ratchet with 9/16" socket

**CONTENTS:** (4) Mounting plates,  
(4) Mounting brackets and  
(8) 3/8" x 3/4" Serrated flange bolts

#### MOUNTING PLATE INSTRUCTIONS



#### ADAGRID™ MOUNTING PLATE

- Freely reposition along accessory bar
- Compatible with most tent and platform accessories
- Quick and easy installation



INSTALLING MOUNTING PLATE

A. Insert (2) mounting brackets in bottom nut channel of ADAGRID™ Accessory Bar.

**IMPORTANT: Ensure extended threads on mounting brackets face up.**

**TIP:** If installing optional accessories, insert mounting hardware in bottom nut channel of accessory bar before attaching to cross bar.

B. With mounting bracket in desired location, align holes in mounting plate with holes in mounting bracket.  
C. Insert bolts through mounting plate into mounting bracket, then finger tighten.

D. Fully tighten and secure all bolts on mounting plate.  
E. Repeat Steps A-D for remaining mounting plates.

**IMPORTANT: Verify mounting brackets are mounted securely before loading cargo or operating truck.**

